





How To Use A Box Bag With A Loose Base

Step 1:



The base sheet is laid on the case base. Desiccant is added & the bag is placed over the machine.

Step 3:



A small gap is left at the end of the seal, and the air is evacuated from the bag with a shop vac.

Please contact us for further information:

Step 2:



The 3D barrier bag is sealed to the base sheet with a hand held heat sealer.

Step 4:



The wooden case is now completed and the packed product is now ready for transit & storage.

info@3dbarrierbags.com (407) 270-9822

www.3dbarrierbags.com (844) 3DB-BAGS

